


Thank you for choosing NABELL Robot-Flex. The below, will help guide you in installing the cover properly.

Installation Precautions

- The images of the products shown are for reference only. Your model may vary slightly
- Remove any peripheral devices before installing the cover to minimize any risk of damage.
- Verify the robot is at rest and powered off before installing your Robot-Flex cover.
- Installation and removal should be performed slowly and carefully.
- Excessive force may cause damage to the robot, cover and/or cause personal injury.
- After installing the cover, check for gaps at the joined areas. Adjust, if necessary.
- Manually move robot, about all axis of rotation to insure smooth movement, before powering on

1. Components and Names



*Each component has its ID number printed for identification.


2. How to mount

① Posture of Robot

- Position the robot and each arm where it is convenient to work with.
- Each component (P1~P6) to be applied shown as in the picture.

〈Component mounting order〉

- **P2→P4→P6→P1→P3→P5**



② Mounting of [P2] (First)

- Detach Velcro and mount the cover. Then fasten Velcro tightly.
- Make sure the outer sliding sheet is lined up straight. (*1) (Do the same for all others)



ズレないようにしっかりと合わせ
「面ファスナー」で固定していきます



(*1)

③ Mounting of [P4]


- Same procedure as P2.



「外付き摺動シート」が
一直線になるように合わせます


④ Mounting of [P6]

- Same procedure as P2.




⑤ Mounting of [P1]

- Detach Velcro and mount the cover.
- Then fasten Velcro tightly.
- Make sure its inner sliding sheet is located over outer sliding sheet of P2.




⑥ Mounting of [P3]

- Detach Velcro and mount the cover.
- Then fasten Velcro tightly.
- Mount to locate the inner sliding sheet to meet over the outer sliding sheets of P2 and P4.



⑦ Mounting of [P5] (Last)

- Mount to locate the inner sliding sheet to meet over the outer sliding sheets of P4 and P6.
- Mounting completed



Contact Information



株式会社 ナベル
NABELL CORPORATION
<https://www.bellows.co.jp>
E-mail:nabell@bellows.co.jp

Headquarters
7-2-3 Yumegaoka, Iga, Mie, 518-0873
TEL: +81-595-21-5060
NABELL USA CORPORATION
208 Charter St Albemarle, NC 28001 U.S.A
TEL:+1-704-986-2455